astrum

SP150

Wireless BT Speaker





User Guide

Thank you for purchasing the Astrum SP150 Speaker. Please read the user manual before use and keep it handy for future reference.

Enjoy the perfect blend of style, functionality, and durability with the Astrum SP150 Bluetooth Speaker, your ideal companion for both indoor and outdoor adventures.

PRODUCT OVERVIEW





FEATURES

Bluetooth Version: 5.3 for a stable and efficient wireless connection.

Power Output: 24W RMS (MAX), delivering powerful and clear sound.

Input Options: AUX input, TF / SD card slot (Max 128 GB), USB-C charging port.

True Wireless Stereo (TWS): Pair two SP150 speakers for a true stereo experience.

Built-in Microphone: Supports hands-free calling for added convenience.

RGB Light: Adds a dynamic and colorful light show to your music.

Waterproof Rating: IPX6, making it resistant to water splashes and suitable for outdoor use.

Battery Life: Up to 5.5 hours of playtime on a single charge, ensuring prolonged entertainment.

Power-Saving Mode: The speaker will automatically power off after 10 minutes if it does not pair with any device.

SPECIFICATIONS

Bluetooth Version	V5.3
Output	24W RMS (MAX)
Speaker	57mm*1
Transmission Distance	10m (open area)
Battery Capacity	1800mAh
Power Supply	USB-C, 5V 1A
Charging time	2 Hours
Playtime	5.5 Hours (50% volume)
Size	L98mm*W68mm*H110.4mm
Weight	410g

PACKAGE CONTENTS

1 x SP150 Speaker
1 x USB-C Charging Cable
1 x User Manual
1 x Aux-in Cable

INSTRUCTIONS

Button	Operation	Function
⏻	Power ON	When the device is powered off, press and hold the power button for 2 seconds to power it on.
	Power OFF	When the device is powered on, press and hold the power button for 2 seconds to power it off.
	Switch LED	While the device is powered on, press the power button three times to switch the LED color.
	TWS	When Bluetooth is not connected, press the button twice to enter TWS mode.
	Mode Switch	Press the button once and wait for beep sound to switch between BT (Bluetooth), Micro SD and AUX modes.
	Play / Pause	In BT, TF card, or AUX mode, press this button once to pause playback and press it again to resume.
▷	Incoming Call Answering	Press this button once to answer an incoming call.
	Rejection	When a call is incoming, press and hold this button for 2 seconds to reject the call.
	End Call	Press this button once during a call to hang up.

▷	Tail Number Redial	Double-click this button to redial the last dialed number.
	Disconnect Bluetooth	Press and hold this button for 3 seconds to disconnect the Bluetooth connection.
−	Volume Down	Press this button once to decrease the volume.
	Previous Track	Press and hold this button for 2 seconds to skip to the previous track.
+	Volume Up	Press this button once to increase the volume.
	Next Track	Press and hold this button for 2 seconds to skip to the next track.

CONNECTIVITY

BT MODE

Power ON the speaker, and the LED light will flash blue, which means it is in Bluetooth mode.

Activate Bluetooth on your device, search for the device name “Astrum SP150” and connect it.

AUX MODE

When a 3.5mm audio cable is plugged in from a device the speaker will automatically play music from the AUX input.

A tone will sound and the blue light will flash slowly when playing.

TF CARD MODE

Insert a TF card, and the speaker will automatically play the music from the card. (Support Max 128GB).

TWS MODE

1. Turn on both speakers. Ensure they are not connected to any other Bluetooth devices to enter the Bluetooth search state.
2. Press the POWER button twice on one of the speakers. When you hear a beep

and the yellow light flashes, the speakers have entered TWS pairing mode.

3. Once in TWS pairing mode, the yellow lights on both speakers will light up simultaneously, and there will be a beep. The main unit's blue light will flash quickly, indicating it is waiting for a device to connect, while the auxiliary unit's blue light will remain on.
4. After the TWS connection is established, the main unit can connect to Bluetooth or AUX to play music, and the auxiliary unit will play the same music simultaneously.
5. To cancel the TWS connection, press the POWER button twice on the main speaker. A prompt sound will be heard, and the yellow light will turn off.

RESET

If the device is unresponsive, press and hold the "POWER" and "PLAY / PAUSE" buttons simultaneously to force shutdown & reset.

SAFETY PRECAUTIONS

Avoid exposing the speaker to extreme temperatures or direct sunlight.

Do not submerge the speaker in water or any other liquid.

Do not attempt to dismantle or repair the speaker yourself. Contact customer service for assistance.

Keep the speaker away from sharp objects to prevent damage.

Do not use the speaker in flammable or explosive environments.

Keep the speaker out of reach of children to avoid accidents.

WARNING

This product contains a Lithium-ion battery. Please do not dispose of it in the fire.

Do not puncture, crush, or disassemble the battery.

Only use the recommended power source for charging the speaker.

Do not overcharge the battery or leave it charging for extended periods.

NOTE Please contact our customer service team for any technical assistance or customer support. Thank you for choosing our product.

®2024 ASTRUM WORLD INC. Astrum is a registered trademark of Astrum World Inc. USA.
All rights reserve. All other trademarks are property of their respective owners.
All specifications and photos are for reference purposes only.