astrum

Wireless
BT Speaker




SP 210


SPEAKER SERIES

Thank you for purchasing the Astrum SP210 Speaker. Please read the user manual before use and keep it handy for future reference.

Enjoy the perfect blend of style, functionality, and durability with the Astrum SP210 Bluetooth Speaker, your ideal companion for both indoor and outdoor adventures.

PRODUCT OVERVIEW





FEATURES

Bluetooth Version 5.3: Ensures stable and efficient wireless connectivity.

Powerful 25W Output: Delivers clear and robust audio for an immersive listening experience.

Multiple Inputs: Supports AUX and TF/SD card (Max 128 GB) for diverse playback options.

TWS (True Wireless Stereo): Pair two SP210 speakers for a true stereo sound experience.

USB-C Charging: Provides fast and convenient charging.

Hands-Free Microphone: Allows you to take calls without disconnecting your device.

RGB Light: Enhances your listening experience with dynamic lighting effects.

IPX6 Water Resistance: Protects the speaker from splashes and light rain, perfect for outdoor use.

Playing Time: Up to 5.5 hours of continuous playtime on a single charge.

Power-saving mode: The speaker will power off automatically after 10 minutes if it is not pair with any device.

SPECIFICATIONS

Bluetooth Version	V5.3
Output	25W
Speaker	66mm*1
Transmission Distance	10m（open area)
Battery Capacity	4000mAh
Power Supply	USB-C, 5V 1A
Charging time	3 Hours
Playtime	5.5 Hours (50% volume)
Size	L107.2mm*W77mm*H124.5mm
Weight	580g

PACKAGE CONTENTS

1 x SP210 Speaker
1 x USB-C Charging Cable
1 x User Manual
1 x Aux-in Cable

INSTRUCTIONS

Button	Operation	Function	LED
⏻	Power ON	When the device is powered off, press and hold the power button for 2s.	The blue light flashes quickly
	Power OFF	When the device is powered on, press and hold the power button for 2s.	The indicator light turns off
	Switch LED	When the device is powered on, press the button once to switch the LED mode.	
	Force Shutdown	If the device is unresponsive. Press and hold the power button for 8s to force the device to shut down.	The indicator light turns off
M	Mode Switch	Short press this button to switch between BT (Bluetooth), SD, USB, and AUX modes.	BT mode: Blue light stay on TF Card / Aux mode: Blue light flashes
	Disconnect Connection	Press and hold this button for 3s to disconnect the current connection.	Blue light flashes quickly
	Reset	Press and hold this button for 12s to reset the device and clear previous operation memory.	Will hear a chime sound

	TWS Mode	When Bluetooth is not connected, press this button twice to enter TWS mode.	Yellow light flashes quickly
	Microphone connection	Press this button once to start karaoke mode.	
	Play / Pause	In BT, TF card, or AUX mode, press this button once to pause playback and press it again to resume.	
	Incoming Call Answering	Press this button once to answer an incoming call.	
	Rejection	Press and hold this button for 2s when a call is incoming to reject the call.	
	End Call	Press this button once during a call to hang up.	
	Redial Last Number	Double-click this button to redial the last dialed number.	
	Voice Assistant	Press and hold this button for 3s to activate the voice assistant.	
	Volume Down	Press this button once to decrease the volume.	
	Previous Track	Press and hold this button for 2s to skip to the previous track.	
	Volume Up	Press this button once to increase the volume.	
	Next Track	Press and hold this button for 2s to skip to the next track.	

CONNECTIVITY

BT MODE

Power ON the speaker, and the LED light will flash blue, which means it is in Bluetooth mode.

Activate Bluetooth on your device, search for the device name “Astrum SP210” and connect it.

AUX MODE

When a 3.5mm audio cable is plugged in from a device, the speaker will automatically play the music provided by AUX. (A tone will sound and the blue light will flash slowly when playing)

TF CARD MODE

Insert a TF card, and the speaker will automatically play the music from the card. (Support Max 128GB).

TWS MODE

Turn on the two speakers (if there are other Bluetooth devices connected, disconnect them to make the speakers in the Bluetooth search state)；

Click twice the TWS button of one of the speakers, when you hear the beep and the yellow light flashes, mean they are entered the TWS pairing mode；

After entered the TWS pairing mode, the yellow lights of the two speakers will light up at the same time and there will be a beep. The blue light of the main machine flashes quickly waiting for the devices to connect, and the blue light of the auxiliary machine is always on；

After the TWS is connected, the main unit is connected to Bluetooth or the main unit is plugged into the AUX to play music, and the auxiliary machine will be corresponding music is also played at the same time；

In the TWS connection state, click the TWS button twice to cancel the TWS connection to the speaker and there will be a prompt sound, and the yellow light will go out.

SAFETY PRECAUTIONS

Avoid exposing the speaker to extreme temperatures or direct sunlight.

Do not submerge the speaker in water or any other liquid.

Do not attempt to dismantle or repair the speaker yourself. Contact customer service for assistance.

Keep the speaker away from sharp objects to prevent damage.

Do not use the speaker in flammable or explosive environments.

Keep the speaker out of reach of children to avoid accidents.

WARNING

This product contains a Lithium-ion battery. Please do not dispose of it in the fire.

Do not puncture, crush, or disassemble the battery.

Only use the recommended power source for charging the speaker.

Do not overcharge the battery or leave it charging for extended periods.

NOTE Please contact our customer service team for any technical assistance or customer support. Thank you for choosing our product.

®2024 ASTRUM WORLD INC. Astrum is a registered trademark of Astrum World Inc. USA.
All rights reserve. All other trademarks are property of their respective owners.
All specifications and photos are for reference purposes only.